



RESOURCE CENTER

SELF VENTING GAS CAN ASSEMBLY INSTRUCTIONS

1. Unscrew the collar by turning the collar counter-clockwise. Depress the child-resistance tab to complete the first rotation.
2. Pop the yellow cap through the collar by simply applying pressure using your thumbs to the center of the yellow cap. Retain the yellow cap for secure storage.
3. After adding fuel to your container, lace the self-venting spout through the collar and place over the neck opening.
4. Screw the spout/collar assembly onto the container by turning clock-wise. The collar should be tightened to the point that it passes the child-resistant tab on the can.
5. For proper storage, store your can with the yellow cap on the end of your self-venting spout with the arrows turned so they are no longer inline.
6. To remove the yellow cap, align the arrow on your yellow cap with the arrow on your self-venting spout.



NEVER STORE SPOUT INSIDE GAS CAN

SAFETY AWARENESS- Always store in a well ventilated area, away from ignition sources, and out of reach of children.



CAUTION

***Never use gas to start a fire.
May cause severe injury or death.***

